

SUSWE 变频器 SUSWE Electric

变频器用户手册 Inverter User Manual

1-单进三出
1-single-in three-out



普通通用系列 微型交流电机驱动器
Simple general series Miniature AC motor driver

第一章 概述

本手册供用户安装调试及维护和使用。

1. 开箱检查

从包装箱中取出变频器, 并确认: 产品外形是否损坏或变形: 元件是否损坏或脱落: 观察机箱侧铭牌的额定值, 核对是否与您的订货要求相一致: 查对装箱单箱内所列物品是否齐全。如有疑问产品损坏, 请立即与供货商联系。

2. 使用前请仔细阅读并妥善保管

3. 使用环境

电源: 单输入AC220V \pm 40%

温度: -10 $^{\circ}$ C-50 $^{\circ}$ C

湿度: 0%-65%

4. 注意事项

接线时, 必须关闭电源。

务必确认, 绝不可将AC电源接至电机输出端。

5. 现场无凝露、粉尘, 无腐蚀性液体/气体。

6. 安装部位坚固, 无振动。

7. 因整体较小, 请处理好接线线头。

8. 如使用环境温度高, 请留出足够的散热空间。

Chapter I Overview

This manual is intended for installation, commissioning, maintenance and use by the user.

1. Unpacking inspection

Remove the Inverter from the box and confirm that: Whether the product appearance is damaged or deformed: Whether the components are damaged or fall off: Observe the rating of the nameplate on the chassis side and check whether it is consistent with your order requirements:

Check whether the items listed in the packing list box are complete. If there is any doubt about the product damage, please contact the supplier immediately.

2. Please read it carefully before use and keep it properly.

3. Use environment.

Power supply: Single input AC220V \pm 40%

Temperature: -10 $^{\circ}$ C - 50 $^{\circ}$ C

Humidity: 0% - 65%

4. Precautions

When wiring, the power supply must be turned off.

Make sure that AC power is never connected to the motor output.


5. There is no condensation, dust and corrosive liquid/gas on the site.

6. The installation position shall be firm and free from vibration.


7. As the overall size is small, please handle the wire ends properly.

8. If the ambient temperature is high, please leave enough heat dissipation space.


第二章 安装与配线




Chapter II Installation and Wiring



开孔尺寸52.5mm*80mm*130mm



Opening size 52.5MM*80MM*130MM



单相三线输出拆电容


单相两线输出不拆电容

编码器输入

Single phase three-wire output capacitance removal

Single phase two wire output without capacitance



Encoder Input




单相电机



单相电机



Single phase motor



第三章 按键说明

以下XXX代表任意数据

(MODE键):此键可查看变频器的设置频率(Fxxx)和工作频率(Hxxx)。

运行电流(Axxx)、电机方向(FWD/REV)输入电压(Uxxx)、变频器温度(TXXX),入点状态(Lxxx),PID参数显示(X。X-X。X)表示给定值/反馈值。

(▲键):设置数据时加数据功能或频率有面板控制时加频率

(▼键):设置数据时减数据功能或频率有面板控制时减频率

(ENTER键):进入Pxxx参数设置时,按此键进入参数模式,修改完成时在按此键保存设置的参数。

(点动键):点动操作功能。(运行键):变频器面板操作开始键。

(STOP/RESET键):按此键在操作模式下停止,按此键可在故障显示模式下清除故障报警功能。

(ENTER+):此键是组合键。在面板锁定模式下,您可以按此键解锁功能。启用面板锁定功能后,可以按此键进入面板锁定功能。

面板设置说明:

当面板显示Pxxx时,您可以按向上和向下箭头按钮调整到指定的参数编号,然后按ENTER键进入此菜单项的数据模式。此数据可以根据以下表修改指定大小的数据。修改完按ENTER键保存。如果面板未显示Pxxx模式时,可以一直按MODE键,直到显示Pxxx为止。

Chapter III Key Description:

XXX below represents arbitrary data

(MODE key):

This key can view the set frequency(Fxxx) and operating frequency (Hxxx) of the frequency converter.

Operating current (Axxx), motor direction(FWD/REV), input voltage(Uxxx), inverter temperature (TXXX),

Input point status(Lxxx),PID parameter display (X.X - X X) indicates setpoint / feedback value.

(▲ key):

Add data function when setting data or add frequency when frequency is controlled by panel.

(▼ key):

Subtract data function when setting data or reduce frequency when frequency is controlled by panel.

(ENTER key):

Press this key to enter parameter mode when entering Pxxx parameter setting, and press this key to save the set parameters after modification.

(JOG key):

Jog operation function.

(RUN key):

Inverter panel operation start key.

(STOP / RESET key):

Press this key to stop in operation mode, and press this key to clear fault alarm function in fault display mode.

(ENTER +):

This key is a composite key. In panel lock mode, you can press this key to unlock the function. When the panel lock function is enabled, you can press this key to enter the panel lock function.

Description of panel settings:

When the panel displays Pxxx, you can press the up and down arrow buttons to adjust to the specified parameter number, and then press the ENTER key to enter the data mode of this menu item. This data can be modified to the specified size according to the following table. After modification, press the ENTER key to save. If the panel does not display Pxxx mode, you can press the MODE key until Pxxx is displayed.

第四章 参数说明

功能/参数一览表

分类	编号	功能说明	设定范围	出厂值
基本参数	P00	主频率输入来源设定	00:主频率输入由数字操作器控制	1
			01:键盘电位器输入,低于最P35设定值输出为0Hz	
			02:键盘电位器输入,低于最P35设定值输出为P45值	
			03:外部模拟量输入,低于最P35设定值输出为0Hz	
			04:外部模拟量输入,低于最P35设定值输出为P45值	
			05:485通讯给定	
	P01	运转信号来源设定	00:运转指令由数字操作器控制	0
			01:运转指令由外部端子控制	
			02:485通信控制	
	P02	电机停车方式设定	00:以减速煞车方式停止	0
			01:在自由运转方式停止	
	P03	电机额定值(最高频率)选择	1.00~400.00Hz	50.00

Chapter IV Parameter Description

List of functions/parameters

Classification	Number	Functional Description	Setting range	Factory value
	P00	Main frequency input source setting	00: Main frequency input is controlled by digital operator 01: Keyboard potentiometer input, output is 0Hz below the maximum P35 setting value 02: Keyboard potentiometer input, output is P45 value below the maximum P35 setting value 03: External analog input, output is 0Hz below the maximum P35 setting value 04: External analog input, output is P45 value below the maximum P35 setting value 05: 485 communication setting 06: PID control mode (PID input has external analog input)	1
	P01	Operation signal source setting	00: Operation command is controlled by digital operator 01: Operation command is controlled by external terminal 02: 485 communication control	0
	P02	Motor stop mode setting	00: Stop by deceleration braking mode 01: Stop by free running mode	0
	P03	Motor rating (maximum frequency) selection	1.00~400.00Hz	50.00

分类	编号	功能说明	设定范围	出厂值
基本参数	P04	最高输出电压选择	230V:0.1~255.0V 460V:0.1~510.0V	220.0
	P05	中间频率选择	0.10~400.0Hz	25.00
	P06	中间电压选择	230V:0.1~255.0V 460V:0.1~510.0V	110.0
	P07	最低输出频率选择	0.10~20.0Hz	01.00
	P08	最低输出电压选择	230V:0.1~255.0V 460V:0.1~510.0V	30
	P09	第一加速时间选择	0.01~600.0s	10.0
	P10	第一减速时间选择	0.01~600.0s	10.0
	P11	第二加速时间选择	0.01~600.0s	010.0
	P12	第二减速时间选择	0.01~600.0s	010.0
	P13	第一段频率设定	0.00~400.0Hz	15.00
	P14	第二段频率设定	0.00~400.0Hz	20.00
	P15	第三段频率设定	0.00~400.0Hz	25.00
	P16	第四段频率设定	0.00~400.0Hz	30.00
	P17	第五段频率设定	0.00~400.0Hz	40.00
	P18	第六段频率设定	0.00~400.0Hz	45.00
	P19	第七段频率设定	0.00~400.0Hz	50.00
	P20	禁止反转功能设定	00:禁止反转 01:可反转 02:方向可保存	1
	P21	载波频率设定	01~15; fc=1kHz~15kHz	08
	P22	直流制动电流准位设定	00~80%	00.0

Classification	Number	Functional Description	Setting range	Factory value
Basic parameters	P04	Maximum output voltage selection	230V:0.1~255.0V 460V:0.1~510.0V	220.0
	P05	Intermediate frequency selection	0.10~400.0Hz	25.00
	P06	Intermediate voltage selection	230V:0.1~255.0V 460V:0.1~510.0V	110.0
	P07	Minimum output frequency selection	0.10~20.0Hz	01.00
	P08	Minimum output voltage selection	230V:0.1~255.0V 460V:0.1~510.0V	30
	P09	First acceleration time selection	0.01~600.0s	10.0
	P10	First deceleration time selection	0.01~600.0s	10.0
	P11	Second acceleration time selection	0.01~600.0s	010.0
	P12	Second deceleration time selection	0.01~600.0s	010.0
	P13	The first frequency setting	0.00~400.0Hz	15.00
	P14	Second frequency setting	0.00~400.0Hz	20.00
	P15	The third frequency setting	0.00~400.0Hz	25.00
	P16	The fourth frequency setting	0.00~400.0Hz	30.00
	P17	The fifth frequency setting	0.00~400.0Hz	40.00
	P18	The sixth frequency setting	0.00~400.0Hz	45.00
	P19	The seventh frequency setting	0.00~400.0Hz	50.00
	P20	Disable reverse function setting	00: Reversal prohibited 01: Reversible 02: Direction can be saved	1
	P21	Carrier frequency setting	01~15; fc=1kHz~15kHz	08
	P22	DC braking current level setting	00~80%	00.0

	P23	启动时直流制动时间设定	0.0~5.0s	0.0
	P24	停止时直流制动时间设定	0.0~25.0s	01.0
	P25	停止时直流制动起始频率	0.00~15.00Hz	02.50
	P26	输出频率上限设定	0.10~400.0Hz	50.00
	P27	输出频率下限设定	0.00~400.0Hz	00.00
分类	编号	功能说明	设定范围	出厂值
基本参数	P28	多功能输入模式选择	0: X0:正转/停止; X1:反转/停止 1: X0:运转/停止; X1:反转/停止 2: X0:正转/停止; X1:反转/停止 X2:点动正转; X3:点动反转 3:多功能输入可编程设置 (X0-X3功能由P29-P32设置)	0
	P29	多功能输入(X0)	0:无功能 1:按减速时间停机 2:自由停车 3:RESET指令	04
	P30	多功能输入(X1)	4:多段速指令一 5:多段速指令二 6:多段速指令三 7:正转/停止 8:反转/停止	05
	P31	多功能输入(X2)	9:运行/停止 10:正转/反转 11:点动正转 12:点动反转	06
	P32	多功能输入(X3)	13:常闭减速停机 14:常开减速停机	07
	P33	任意到达频率设定	0.00~400.0Hz	00.00

	P23	DC braking time setting at start-up	0.0~5.0s	0.0
	P24	DC braking time setting when stopping	0.0~25.0s	01.0
	P25	DC braking starting frequency when stopping	0.00~15.00Hz	02.50
	P26	Output frequency upper limit setting	0.10~400.0Hz	50.00
	P27	Output frequency lower limit setting	0.00~400.0Hz	00.00
Classification	Number	Functional Description	Setting range	Factory value
Basic parameters	P28	Multi-function input mode selection	0: X0: forward/stop; X1: reverse/stop 1: X0: Run/Stop; X1: Reverse/Stop 2: X0: forward/stop; X1: reverse/stop X2: jog forward; X3: jog reverse 3: Multi-function input programmable settings (X0-X3 functions are set by P29-P32)	0
	P29	Multi-function input (X0)	0: No function 1: Stop according to deceleration time 2: Free stop 3: RESET command	04
	P30	Multi-function input (X1)	4: Multi-speed command 1 5: Multi-speed command 2 6: Multi-speed command 3 7: Forward/stop 8: Reverse/stop	05
	P31	Multi-function input (X2)	9: Run/stop 10: Forward/reverse 11: Jog forward 12: Jog reverse 13: Normally closed deceleration stop 14: Normally open deceleration stop	06
	P32	Multi-function input (X3)		07
	P33	Any frequency setting	0.00~400.0Hz	00.00

P34	转矩补偿增益	00~10	00.0
P35	AVI最小给定	0.0V~P36	1.0
P36	AV最大给定	P35~10.0V	9.5
P37	异常后,自动重置/启动次数设定	00~10	00
P38	异常后,自动重置/启动间隔时间设定	0.0~20s	00.0
P39	模拟输出增益设定	00~200%	082
P40	电源启动运转锁定	00: 可运转 01: 不可运转	0
P41	多功能输出RELAY接点	00: 运转中指示 01: 设定频率到达指示 02: 任意频率到达指示 03: 故障指示	03
P42	参数锁定/重置设定	00: 所有的参数值设定可读/写模式 01: 所有的参数设定为仅读模式	0
P43	设定频率	0.00~400.00Hz	05.00
P44	启动时直流制动频率	0.00~15.00Hz	0.50

P34	Torque compensation gain	00~10	00.0
P35	AVI minimum setting	0.0V~P36	1.0
P36	AV maximum setting	P35~10.0V	9.5
P37	Automatic reset/start times setting after abnormality	00~10	00
P38	Automatic reset/restart interval setting after abnormality	0.0~20s	00.0
P39	Analog output gain setting	00~200%	082
P40	Power on operation lock	00: Operable 01: Inoperable	0
P41	Multi-function output relay contact	00: Indication of operation 01: Indication of reaching the set frequency 02: Indication of reaching any frequency 03: Fault indication	03
P42	Parameter lock/reset settings	00: All parameter values are set to read/write mode 01: All parameters are set to read-only mode	0
P43	Setting frequency	0.00~400.00Hz	05.00
P44	DC braking frequency at start-up	0.00~15.00Hz	0.50

分类	编号	功能说明	设定范围	出厂值
普通参数	P45	模拟量低端频率	0.00~400.00Hz	0
	P46	故障清除	0	0
	P47	故障记录1	*	No
	P48	故障记录2	*	LU
	P49	故障记录3	*	No
	P50	故障记录4	*	No
	P51	最新故障记录项	47~50	48
	P52	电机额定电流	0-65000	3.2
	P53	电机空载电流	0-65000	1.0
	P54	电转差补偿系数	0-1000	0
普通参数	P55	电机过载保护方式	0:热等效保护方式 1:等时保护方式	01
	P56	电机过载保护准位	0~300%	150%
	P57	电机过载保护时间	0~600.0S	60.0S
	P58	过压失速电压	0~999.9V	370.0V
	P59	加速中失速防止电流准位	0~300%	150%
	P60	恒速中失速防止电流准位	0~300%	150%
	P61	减速中失速防止电流准位	0~300%	150%
	P62	恒速过流减速时间	0~600.0S	5.0S

Classification	Number	Functional Description	Setting range	Factory value
Common parameters	P45	Analog low-end frequency	0.00~400.00Hz	0
	P46	Fault clearing	0	0
	P47	Fault record 1	*	No
	P48	Fault record 2	*	LU
	P49	Fault record 3	*	No
	P50	Fault record 4	*	No
	P51	Latest fault record item	47~50	48
	P52	Motor rated current	0-65000	3.2
	P53	Motor no-load current	0-65000	1.0
	P54	Electric slip compensation coefficient	0-1000	0
Common parameters	P55	Motor overload protection mode	0: Thermal equivalent protection mode 1: Isochronous protection mode	01
	P56	Motor overload protection level	0~300%	150%
	P57	Motor overload protection time	0~600.0S	60.0S
	P58	Overvoltage stall voltage	0~999.9V	370.0V
	P59	Acceleration stall prevention current level	0~300%	150%
	P60	Constant speed stall prevention current level	0~300%	150%
	P61	Deceleration stall prevention current level	0~300%	150%
	P62	Constant speed overcurrent deceleration time	0~600.0S	5.0S

分类	编号	功能说明	设定范围	出厂值
	P63	启动方式选择	0:从启动频率加速启动 1:频率跟踪启动	0
	P64	故障重启启动方式选择	0:故障重启从启动频率加速启动 1:故障重启按频率跟踪启动	0
	P65	加减键频率调整步进值	0~400.0Hz	0.10Hz
	P66	DAC输出选择	0:设置频率 1:输出频率 2:输出电流 3:母线电压 4:变频器温度	09
	P67	参数恢复出厂值	1:手动保存参数 8:恢复出厂值 其他值:无效	0
	P68	频率跟踪电流准位	0~300%	150%
	P69	频率跟踪时间	0~900.0S	3.0S
	P70	频率跟踪电压上升时间	0~900.0S	3.0S
	P71	点动频率	0~400.0Hz	10.00Hz
	P72	多段速加减速时间选择	0~255按2进制加权设置 Bit1~bit7分别对应P13~P19 0:加减速时间1 1:加减速时间2	000
	P73	变频器额定电压	0~550.0V	220.0
	P74	变频器额定电流	0~6500.0A	07.0

Classification	Number	Functional Description	Setting range	Factory value
	P63	Startup method selection	0: Start from the starting frequency and accelerate 1: Start by tracking the frequency	0
	P64	Fault restart startup mode selection	0: Fault restart starts from the start frequency 1: Fault restart starts by tracking the frequency	0
	P65	Plus and minus key frequency adjustment step value	0~400.0Hz	0.10Hz
	P66	DAC Output Selection	0: Set frequency 1: Output frequency 2: Output current 3: Bus voltage 4: Inverter temperature	09
	P67	Parameters restored to factory values	1: Manually save parameters 8: Restore factory values Other values: Invalid	0
	P68	Frequency tracking current level	0~300%	150%
	P69	Frequency tracking time	0~900.0S	3.0S
	P70	Frequency tracking voltage rise time	0~900.0S	3.0S
	P71	Jog frequency	0~400.0Hz	10.00Hz
	P72	Multi-speed acceleration and deceleration time selection	0~255 is set in binary weighted mode Bit1~bit7 correspond to P13~P19 respectively 0: Acceleration/deceleration time 1 1: Acceleration/deceleration time 2	000
	P73	Inverter rated voltage	0~550.0V	220.0
	P74	Inverter rated current	0~6500.0A	07.0

工厂参数	P75	变频器过载保护准位	0~300%	150%
	P76	变频器过载保护时间	0~600.0S	60.0S
	P77	过压保护电压	0~999.9V	400.0V
	P78	欠压保护电压	0~999.9V	245.0V
	P79	电流检测系数	0~65535	30
	P80	电压检测系数	0~65535	1250
	P81	输出交流电压系数	0~65535	1000
	P82	IO输入滤波系数	0~65535	50
	P83	风扇启动温度	0~80	50
	P84	电机类型	0:三相输出	0
	P85	变频器类型	0:通用变频器	0
	P86	死区时间	0~250	30
	P87	外部制动输出百分比	0-100	0
	P88	软件版本号	*	27.39
	P89	保留	*	0000
	P90	密码	*	0000
P91	速度显示	相对于最高频率所对应的最高转速	1500	
P92	控制模式	0:VF控制	0	

Classifi-cation	Number	Functional Description	Setting range	Factory value
Factory parameters	P75	Inverter overload protection level	0~300%	150%
	P76	Inverter overload protection time	0~600.0S	60.0S
	P77	Overvoltage protection voltage	0~999.9V	400.0V
	P78	Undervoltage protection voltage	0~999.9V	245.0V
	P79	Current detection coefficient	0~65535	30
	P80	Voltage detection coefficient	0~65535	1250
	P81	Output AC voltage coefficient	0~65535	1000
	P82	IO input filter coefficient	0~65535	50
	P83	Fan start temperature	0~80	50
	P84	Motor Type	0: Three-phase output	0
	P85	Inverter Type	0: General inverter	0
	P86	Dead time	0~250	30
	P87	External brake output percentage	0-100	0
	P88	Software version number	*	27.39
	P89	reserve	*	0000
	P90	password	*	0000
P91	Speed display	The maximum speed corresponding to the maximum frequency	1500	
P92	Control Mode	0: VF control	0	

普通扩展参数	P93	VF曲线	0:直线VF曲线	0
	P94	母线电压滤波时间	10~1000MS	10
	P95	输出电流采样滤波时间	10~10000MS	05.00S
	P98	面板显示锁定项	0-7(0为无锁定功能, ENTER+DOWN键启用锁定功能)	0
	P99	过流保护检测灵敏度	0-9(0位禁止过流保护)	5
通讯与PID控制参数	P100	485通讯地址	1-255	8
	P101	通讯格式 (Modbus RTU 8位数据, 无校验, 1位停止位) 40000开始地址代表P00	0=1200,1=2400,2=4800,3=9600,4=19200,5=38400 6=57600,7=115200 读P00示例(站号 03 9C40 0001 CRCL CRCH) 写P00=1 示例(站号 10 9C40 0001 02 0001 CRCL CRCH) 波特率改变需要重启变频器才能生效	3
	P102	485频率给定值	0-400.00	15.00
	P103	485运行设置	每一位代表不同的功能 Bit0; 0=停机, 1=运行 Bit1 0=正转, 1=反转 Bit2; 0=点动停车, 1=强制点动运行 Bit3; 0=减速停车, 1=自由停车, 2=刹车停车	0000
	P104	保留		0
	P105	保留		0

Classification	Number	Functional Description	Setting range	Factory value
Common extension parameters	P93	VF Curve	0: Straight line VF curve	0
	P94	Bus voltage filter time	10~1000MS	10
	P95	Output current sampling filter time	10~10000MS	05.00S
	P98	Panel Display Locked Items	0-7 (0 means no lock function, ENTER+DOWN key enables lock function)	0
	P99	Overcurrent protection detection sensitivity	0-9 (0 position disables over-current protection)	5
Communication and PID control parameters	P100	485 Correspondence Address	1-255	8
	P101	Communication format (Modbus RTU 8-bit data, no parity, 1 stop bit) 40000 start address represents P00	0=1200,1=2400,2=4800,3=9600,4=19200,5=38400 6=57600,7=115200 Read P00 example (station number 03 9C40 0001 CRCL CRCH) Write P00=1 example (station number 10 9C40 0001 02 0001 CRCL CRCH) Baud rate changes require the inverter to be restarted to take effect	3
	P102	485 frequency given value	0-400.00	15.00
	P103	485 Run Settings	Each bit represents a different function Bit0; 0=stop, 1=run Bit1 0=forward, 1=reverse Bit2; 0=jog stop, 1=forced jog run Bit3; 0=deceleration stop, 1=free stop, 2=brake stop	0000
	P104	reserve		0
	P105	reserve		0

分类	编号	功能说明	设定范围	出厂值
	P106	PID配置	个位:0=单项,1=双向 十位:0=负作用,1=正作用 百位:0=PID故障不报警 1=减速停车,2自由停车	100%
	P107	PID输出限制	0-100	100%
	P108	PID给定信号选择	0:键盘按键给定 1:键盘电位器给定 2:AI1外部模拟量给定 3:AI2外部模拟量给定	0
	P109	PID反馈信号选择	0:键盘按键给定 1:键盘电位器给定 2:AI1外部模拟量给定 3:AI2外部模拟量给定	2
	P110	PID积分时间	0.001-9.999	0.250 S
	P111	PID微分时间	0.000-9.999	0010 S
	P112	PID比例增益	0.000-9.999	3000
	P113	PID采样周期	0.001-9.999	0.010S
	P114	PID偏差极限	0.0-20.0	00.2
	P115	PID故障检测时间	0.0-9.9	180.0S
	P116	PID故障检测值	0.0-100.0	0.2%
	P117	PID显示范围	0.00-1.99	10.00
	P118	PID键盘给定值	0.0-9.9	25.0

Classification	Number	Functional Description	Setting range	Factory value
	P106	PID Configuration	Units: 0 = single-action, 1 = double-action Tens: 0 = negative action, 1 = positive action Hundreds: 0 = no alarm for PID failure 1 = deceleration stop, 2 = free stop	100%
	P107	PID output limit	0-100	100%
	P108	PID given signal selection	0: Keyboard key setting 1: Keyboard potentiometer setting 2: AI1 external analog setting 3: AI2 external analog setting	0
	P109	PID feedback signal selection	0: Keyboard key setting 1: Keyboard potentiometer setting 2: AI1 external analog setting 3: AI2 external analog setting	2
	P110	PID integral time	0.001-9.999	0.250 S
	P111	PID differential time	0.000-9.999	0010 S
	P112	PID proportional gain	0.000-9.999	3000
	P113	PID sampling period	0.001-9.999	0.010S
	P114	PID deviation limit	0.0-20.0	00.2
	P115	PID fault detection time	0.0-9.9	180.0S
	P116	PID fault detection value	0.0-100.0	0.2%
	P117	PID display range	0.00-1.99	10.00
	P118	PID keyboard given value	0.0-9.9	25.0

分类	编号	功能说明	设定范围	出厂值
恒压供水参数	P122	启动压力偏差	0.0-9.9	01.0
	P123	启动延时时间	0.0-32.000	001.0S
	P124	停机频率	0.0-400.0	20.00Hz
	P125	停机延时时间	0.0-32.000	002.0S
输入输出功能扩展	P137	输入端口极性	0常开输入 1常闭输入 个位:0=X0以及X1都为常开, 1=X0常闭X1常开, 2=X0常开X1常闭 3=X0以及X1都为常闭 十位:0=X2以及X3都为常开, 1=X2常闭X3常开, 2=X2常开X3常闭 3=X2以及X3都为常闭	0000
	P138	输入端口类型	0:点动输入断开停止型 1:点动输入断开保持型(参考P137)	0000

Classification	Number	Functional Description	Setting range	Factory value
Constant pressure water supply parameters	P122	Start pressure deviation	0.0-9.9	01.0
	P123	Start delay time	0.0-32.000	001.0S
	P124	Shutdown frequency	0.0-400.0	20.00Hz
	P125	Shutdown delay time	0.0-32.000	002.0S
Input and output function expansion	P137	Input port polarity	0 Normally open input 1 Normally closed input Units: 0=X0 and X1 are both normally open, 1=X0 is normally closed and X1 is normally open, 2=X0 is normally open and X1 is normally closed 3=X0 and X1 are both normally closed Tens: 0=X2 and X3 are both normally open, 1=X2 is normally closed and X3 is normally open, 2=X2 is normally open and X3 is normally closed 3=X2 and X3 are both normally closed	0000
	P138	Input port type	0: Stop when jog input is disconnected 1: Hold when jog input is disconnected (refer to P137)	0000

第五章 故障代码

报警类型	故障说明	故障注解	故障编号
OC	瞬间过流	故障注解	3
OCA	加速过流	检测电机是否正常	4
OCD	减速过流	适当调整加速时间	5
OCN	恒速过流	适当调整减速时间	6
OU	过压	检查机器是否正常电压是否稳定	7
LU	欠压	适当调整加减速时间, 已经市电是否正常	8
OH	变频器过热	检测市电是否正常180V-240V	9
EF	外部故障	检测变频器是否散热正常	10
ERS	故障重启失败	检测外部传感器,输入是否正常	11
LP	输入缺相	重启变频器	12
OL1	电机过载	检测市电是否正常	13
OL2	变频器过载	检测电机是否正常,以及负载是否过重	14
OL3	电机暂时过载	检查电机是否正常,已经是否跟变频器功率匹配	15
OL4	变频器暂时过载	检测负载是否跟电机匹配	16
485	通讯故障	检查电机是否跟变频器功率匹配	17
PID	PID故障	检测通讯线是否正常,以及上位机通讯是否正常	18
CU	无故障报警	检测模拟量输入是否输出,传感器是否正常	21

Chapter 5 Fault Codes

Alarm Type	Fault Description	Fault Notes	Fault number
OC	Instantaneous overcurrent	Fault explanation	3
OCA	Acceleration overcurrent	Check whether the motor is normal	4
OCD	Deceleration overcurrent	Adjust the acceleration time appropriately	5
OCN	Constant overcurrent	Adjust the deceleration time appropriately	6
OU	Overpressure	Check whether the machine is normal and the voltage is stable	7
LU	Undervoltage	Adjust the acceleration and deceleration time appropriately and check whether the mains power is normal.	8
OH	Inverter overheating	Check whether the mains power is normal 180V-240V	9
EF	External fault	Check whether the inverter is cooling normally	10
ERS	Fault restart failure	Check external sensor, whether the input is normal	11
LP	Input phase loss	Restart the inverter	12
OL1	Motor overload	Check whether the mains power is normal	13
OL2	Inverter overload	Check whether the motor is normal and whether the load is too heavy	14
OL3	Temporary overload of motor	Check whether the motor is normal and whether it matches the inverter power.	15
OL4	The inverter is temporarily overloaded.	Check whether the load matches the motor	16
485	Communication failure	Check whether the motor matches the inverter power	17
PID	PID Failure	Check whether the communication line and the host computer communication are normal	18
CU	No fault alarm	Check whether the analog input is output and whether the sensor is normal	21

分类	ModBus 485状态反馈地址 (EDC)	功能	注解
变频器 485 通讯状态	40180	运行状态	Bit0-bit3(运行状态) 1=停止 (Bit0-Bit3>1)=运行
		运行方向	Bit4-bit7(运行方向) 0=正转 1=反转
	40181	变频器当前设定频率	变频器当前的设定频率
	40182	变频器当前运行频率	变频器当前实时运行频率
	40183	变频器运行电流	变频器工作的运行电流
	40184	变频器运行电压	变频器当前的工作电压(这个电压是内部直流电压)
	40185	变频器温度	变频器当前的运行温度
	40186	给定压力	用于恒压供水给定压力用
	40187	反馈压力	用于恒压供水压力反馈用
	40188	外部端子输入状态	反馈外部输入状态
	40189	故障报警	报警代码请参考故障报警列表中的编号
	40198	故障清除	写入大于0的数为清除故障

Classification	ModBus 485 status feedback address (EDC)	Function	Annotation
Inverter 485 communication status	40180	Running status	Bit0-bit3 (operating status) 1 = stop (Bit0-Bit3>1) = running
		Running direction	Bit4-bit7 (running direction) 0 = forward 1 = reverse
	40181	The current setting frequency of the inverter	The current setting frequency of the inverter
	40182	Current operating frequency of the inverter	The current real-time operating frequency of the inverter
	40183	Inverter operating current	The operating current of the inverter
	40184	Inverter operating voltage	The current working voltage of the inverter (this voltage is the internal DC voltage)
	40185	Inverter temperature	The current operating temperature of the inverter
	40186	Given pressure	Used for constant pressure water supply with given pressure
	40187	Feedback pressure	For constant pressure water supply pressure feedback
	40188	External terminal input status	Feedback external input status
	40189	Fault alarm	For alarm codes, please refer to the numbers in the fault alarm list.
	40198	Fault clearing	Write a number greater than 0 to clear the fault.

第六章 保修协议

- 1) 本产品自购买日起一年内享有保修服务, 保修期内按照使用说明书正常使用情况下, 产品发生故障或损坏, 我公司负责免费维修。
- 2) 保修期内, 因以下原因导致损坏, 将收取一定的维修费用:
 - A、因使用上的错误及自行擅自修理、改造而导致的机器损坏;
 - B、由于火灾、水灾、电压异常、其它天灾及二次灾害等造成的机器损坏;
 - C、购买后由于人为摔落及运输导致的硬件损坏;
 - D、不按我司提供的用户手册操作导致的机器损坏;
 - E、因机器以外的障碍(如外部设备因素)而导致的故障及损坏;
- 3) 产品发生故障或损坏时, 请您正确、详细的填写《产品保修卡》中的各项内容。
- 4) 维修费用的收取, 一律按照我公司最新调整的《维修价目表》为准。
- 5) 本保修卡在一般情况下不予补发, 诚请您务必保留此卡, 并在保修时出示给维修人员。
- 6) 在服务过程中如有问题, 请及时与我司代理商或我公司联系。

Chapter 6 Warranty Agreement

- 1) This product comes with a one-year warranty service from the date of purchase. During the warranty period, if the product malfunctions or is damaged under normal use according to the user manual, our company is responsible for free repair.
- 2) During the warranty period, if damage occurs due to the following reasons, a certain repair fee will be charged:
 - A、Machine damage caused by usage errors and unauthorized repairs or modifications;
 - B、Machine damage caused by fire, flood, abnormal voltage, other natural disasters, and secondary disasters;
 - C、Hardware damage caused by human dropping and transportation after purchase;
 - D、Machine damage caused by not following the user manual provided by our company;
 - E、Malfunctions and damages caused by obstacles outside the machine (such as external equipment factors);
- 3) When the product malfunctions or is damaged, please fill in the contents of the "Product Warranty Card" correctly and in detail.
- 4) The collection of maintenance fees shall be subject to the latest adjusted "Maintenance Price List" of our company.
- 5) This warranty card is generally not reissued. Please make sure to keep this card and show it to the repair personnel during the warranty period.
- 6) If there are any problems during the service process, please contact our agent or our company in a timely manner.



SUSWE

Suzhou SUTE Electronic Technology Co., Ltd

